


Olaf Gets Serviced Playdaddy Mega



12: Foundation 13: Clip 14: Continuation

This Mini DV is a high definition video recorder with simple operation or sound control. elegant design, small size, it is easy to carry. It is an essential utility in business, education, security, media, justice, tourism, health care, living and other field.

3. Operation Guide

1. Charge
The battery is built-in lithium rechargeable battery, so when you use it the first time, please charge fully first. The method for charging is as follows:
1) Connect computer: use USB cable to connect the computer, then it can be charged.
2) Use adaptor: connect charge plug with USB cable, then plug into electrical connector receptacle, it can be charged.

3. Operation Guide

- Open the battery cover**
1. Charge the battery is built-in lithium rechargeable battery, so when you use for the first time, please charge firstly. The method for charging is as following:
- 1) Connect computer to USB cable to connect the computer, then it can be charged.
 - 2) Use adaptor or computer charger with USB cable, then plug into electrical connector or receptacle. If you charge it, green light and red light will bright simultaneously, of which states are stillness.
- When battery power is not enough, D6001 will enter into protection mode, so it cannot be turn on. Now, please charge it for 1.
2. Power on or turn light
- Press Power button slowly, yellow indicator light begins to bright, now it enters into startup status. When the battery is fully charged, yellow indicator light quickly becomes "Red". Second "Red" yellow indicator light begins to bright, red indicator light begins to flash slowly. At this time it begins to make a video. The resolution for video file is 720*480, and frame number is

29–30fps/S. Then short press Record / Stop button, video is stopped and saved automatically. After saving the red indicator light remains light. If you need to continue to video, please press Record / Stop button slightly once more.

- a. Please make sure T-flash (Micro SD) card has been inserted, if not, it will be power off automatically after 30 seconds.
- b. The maximum capacity of T-flash card is 16GB.
- c. Saving file needs certain time, so please don't press Operation button continuously in order to avoid saving unsuccessfully and generating incomplete file.
- d. When you make a video, please focus on the object and keep 50cm under sufficient illumination. Then the video will be right, natural color, clear and stable.

Press Power button slightly, yellow indicator light begins to bright, now it enters into standby ready mode, which can enter into standby mode quickly. At that time, press MODE button (triangle), and then you can switch into sound control video mode. Now yellow indicator light

When decibel of video is more than 60, then it will be video automatically. At the moment, yellow indicator light always brights, red indicator light flash slowly. (Indicate under sound

When sound control starts, the shortest shoot time is 2 minutes. After 2 minutes, if there is no any sound, D001 will save file automatically and switch into standby mode. If there still

4. Time set
There is a CD with the product which contains a file named time synchronization file. Please copy it to TE card. When connect D001 with computer, whose time will be displayed

1. build a text called TAGTXT under root directory of card.

2. open TAG.TXT, write synchronous date according to enclosure strictly.
Details as following:
[date] need space with newline
2009-07-23 10:00:00

Power on the machine everytime, system will check and analyze TAGTXT, then set system time according to file time. After that the text will be deleted by system.

5. Power off
Under video mode or standby mode, please long press Power button 3 seconds, then release

- c. When you shoot video without manual record, file will be saved automatically, then

b. When disk space of MINI DV is not enough, after indicator goes out immediately, file will be saved automatically, then auto-power off.

7. Connecting computer

When you connect it with USB port, a portable disk mark will be seen after several seconds. Red indicator light always blinks, yellow indicator light will be on from the back quickly to

1. When you connect computer, if the machine cannot be identified, or not see the portable

b. It is better copy or cut video file into computer hardware then play. Video file which is saved in the machine is played directly will cause unsmooth play, the reason is that gigantic

8. PC Camera
When you first use PC camera, please install driver. The driver name is SPCA528 V2230 M. Seng.exe, which is placed in attached CD. When you install

Under power off or power on mode, use USB cable to connect computer, the mode is U disk.

mode. Then short press **MODE** button, at this moment it can be switched into PC camera mode. Then double press **AMCAP** icon can be used as PC camera.

The specific operation method as following:
Use allen pole to press the Reset button, and then finish one reset operation.

10. Notice
Suitable using situation: Please follow State's law. Do not use it illegally.
Software upgrade: In order to make products have more function, manufacturer will perfect

Work temperature: Please use it under normal temperature and avoid using under unsuitable

Work humidity: Please use it under agreeable human atmosphere humidity, Please not to make product wet or expose in rain for which without waterproof function.

Cleaning requirements. Please do not use the product under too large dust density atmosphere or in places with strong vibration, otherwise the optical lens and other components will be damaged.

Waste treatment: Please pay attention to protect environment, not to throw the product optionally. In order to avoid explosion, please not throw product into fire.

Item	Parameters
Video format	AVI
Video encoding	M-PEG
Video resolution	720*480 VGA
Video frame rate	30fps ± 1 fps
Media playing software	Any software of the operating system or Mainstream audio and video media playing software, recommended Kmpayer
The ratio of image	4:3
Supporting system	Windows me/2000/xp/2003/vista/ Mac OS10.4+
Charge processor	DC-5V
Interface type	Mini 5 pin USB
Storage support	Micro SD (TF)
Battery type	high-capacity lithium polymer

- **Application:** Products strictly adhere relevant regulations and laws. This product should not be used for any illegal purposes. The user is fully responsible for its using purpose.
- **Battery:** If you do not use this recording mode after long time, please charge it fully.
- **File security:** This product is not a professional storage device. It does not guarantee the integrity and security of saved files. Please back up your important documents on the computer or other storage device timely.
- **Video quality:** This product is not a professional video recording device. It does not guarantee the effect of the video to be as good as the professional quality.
- **Operating temperature:** -20~40°C. For the extension of life, it is best used at room temperature.
- **Operating humidity:** 20%~85%. This product does not have the waterproof mode. So it can't be used under the harsh environment.
- **Lighting:** This product is not a professional video camera. It does not directly see the light, so it needs to avoid to optical devices.
- **Clearing:** Do not set it under the environment with high dust density to avoid the contamination of camera lens or other components.

DOWNLOAD: <https://tinurli.com/295v8q>

Free Download



a9c2e16639

[Spiritalized - Let It Come Down](#)
[autocom delphi 2013.1 keygen download](#)
[enid blyton books free download malory towers book](#)
[3DTitles EZTitles V4 Incl Crack English-SURYADEWAALIBESTI](#)
[Pranam Walekum nam full movie free download](#)
[SIEMENS PLM NX 7.5 MAGNITUDE documentation crack](#)
[Download Ittefaq Movie In Mp4](#)
[solucionario de libro fundamentos de fisica de frank j blatt rapidshare](#)
[Eric Conrad Cissp 11th Hour Book](#)
[Dgflck Album Express Software Free Download With Crack](#)